

Гарантийный талон №

irit®

Наименование изделия Чайный набор электрический

Номер модели IR-1502

Серийный номер ZNY11062021

Дата продажи « » 20 г.

М.П.
торгующей
организации

Условия гарантии:

Уважаемый покупатель! Вы приобрели изделие, произведенное под ТМ "IRIT". Данный талон дает Вам право на устранение дефектов изделия в авторизованных сервисных центрах в течении 12 месяцев со дня продажи. Все условия гарантии осуществляются в соответствии с действующим законодательством. Проследите, чтобы данный талон был правильно заполнен и имел печать торгующей организации.

В случае возникновения неисправностей техники в течение гарантийного срока, Вы можете обратиться в авторизованный сервисный центр, адреса и телефоны которых указаны на обороте гарантитного талона. Сервисный центр производит ремонт или выписывает акт, в случае невозможности ремонта данного изделия. На основании этого акта Вы можете обратиться в торговую организацию, в которой было приобретено изделие, для обмена.

После истечения гарантийного срока сервисные центры, указанные в гарантитном талоне, всегда готовы предложить Вас свои услуги по ремонту бытовой техники "IRIT".

Гарантия не включает в себя периодическое обслуживание, установку, настройку и чистку изделия, порядок которых изложен в Инструкции по эксплуатации.

Гарантитное обслуживание не производится при:

- несоблюдении правил эксплуатации изделия, установленных Инструкции по эксплуатации;
- утрате гарантитного талона;
- ремонте неуполномоченнымми на это лицами, а также при других, непредусмотренных инструкцией вмешательства;
- механических повреждениях, возникших по вине потребителя;
- использовании изделия в целях, для которого оно не предназначено;
- внесение изменений и/или исправлений в текст данного талона.

С внешними данными и комплектацией товара ознакомлен: _____ (подпись)

Сохраняйте гарантитный талон и чек контрольно-кассовой машины на изделие. Без предъявления данного талона, его неправильном заполнении и/или отсутствии печатей торгующей организации на талоне и корешках, претензии к качеству не принимаются.

КОРЕШОК К ТАЛОНУ №	
Модель: irit	
Дата продажи	
« » 20 г.	
Наименование Чайный набор электрический	
Модель IR-1502	
Сер. номер ZNY11062021	
Ф.И.О. клиента	
Телефон	
Адрес	
М.П. торгующей организации	
Подпись продавца	

КОРЕШОК К ТАЛОНУ №	
Модель: irit	
Дата продажи	
« » 20 г.	
Наименование Чайный набор электрический	
Модель IR-1502	
Сер. номер ZNY11062021	
Ф.И.О. клиента	
Телефон	
Адрес	
М.П. торгующей организации	
Подпись продавца	

Description

1. Kettle's lid
2. ON/OFF button
3. Kettle's handle
4. Body
5. Base
6. Heating function ON/OFF Switch
7. Teapot's lid
8. Teapot's handle
9. Tea strainer
10. Heating indicator light
11. Boiling indicator light



Warning!

- Please read the owner's manual carefully before using the product.
- Check if the voltage of the kettle corresponds to the local main voltage before you connect the appliance.
- Because of lack of water inside of the kettle the security system will work and the kettle will be turned off.
- If the kettle has worked without water, firstly, unplug it from the mains, fill kettle with cool water. As soon as heating element cools down, security system will be turned off.
- Put the kettle on a stable flat surface. Pour first boiled water, after that the kettle ready for using.
- While using the kettle's lid should be kept tightly closed.
- When water starts boiling, the kettle will be turned off automatically. You can switch it off before the water is boiling.
- The glass cup is easy broken, please take care.

Important safeguards

- DO NOT plug an empty kettle.
- Use the kettle for boiling water only.
- In order to protect children from the dangers of electrical appliances, never leave them unsupervised with the appliance.
- Be careful while filling the kettle, don't exceed the prescribed maximum water level for avoiding injuries.
- DO NOT touch hot surface of the kettle. Be careful with the hot steam.
- Under no circumstances must the device be placed in water or other liquid, or come into contact with such. Do not use the device with wet or moist hands.
- Should the device become moist or wet, remove the mains plug from the socket immediately.
- Please do not place the empty glass cup on the heater base, when it's powered on.
- Do not try to repair the appliance on your own. If any troubles are found, apply to the nearest service center for support.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

irit®

MANUAL INSTRUCTION ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

Чайный набор электрический Electric tea set

IR-1502



Filling of the Kettle

- Open the kettle's lid.
- Fill the kettle with the desired amount of water.
- The water level should be between the minimum and maximum mark of the kettle.
- Do not fill above the maximum level indicator (marked on the water gauge as "MAX") as water may spill out of the spout when boiling.
- Push the lid closed firmly until it locks into position.

Switching

- Place the kettle on the power base.
 - Plug in the appliance.
 - Turn the ON/OFF button, the light indicator will light up and remain on while water is boiling.
- Remember that the kettle's lid should be kept tightly closed while using the appliance.

Turning off

- After boiling the machine switches off automatically. The control lamp on the water level indicator shows that the water is being boiled.
- You can manually turn off the kettle in any time.
- Warning! Repeated switching on of the kettle before its cooling can cause damage of the operating mechanism. Allow the kettle to cool before filling with cold water and re-boiling.

Cleaning

- Always remove the plug from the mains supply and allow it to cool before cleaning the appliance!
- The exterior of the machine should be cleaned, if necessary, with a slightly damp cloth without additives.
- Never put cleaning detergents into the kettle. This will make the operation unsafe and damage the unit.

Descaling

- Kettle should be descaled regular.
- It is recommended to clean the inside of the kettle once a month.
- For descaling, use a special cleaner for kettles.
- After that wash the kettle with clean water.

The importer retains his right to make changes in appearance and completeness of the item without preliminary notification to the customer.

For household usage only.

Do not leave unattended!

The date of manufacture is marked on the packaging.

TECHNICAL PARAMETERS

Voltage: 220-240V/50Hz

Power: 1500 W

Kettle capacity - 1,8 L, teapot capacity - 0,8 L

Service life is 2 years

Made in China



